




Attention: Connect AVCC to UCC  
and AUSS to GND





Controller	
TITLE: FE427_Ref_Board	
Document Number:	REV: 2.3
Date: 23.01.2004 10:13:08	Sheet: 1/3

TITLE: FE427\_Ref\_Board

Document Number:	REV:
------------------	------

Date: 23.01.2004 10:13:08 Sheet: 1/3





# Power Supply

TITLE: FE427\_Ref\_Board

Document Number:

REV: 2.3

Date: 23.01.2004 10:13:08

Sheet: 3/3

MSP430FE427 Ref. Board  
Ver: 2.3

